

ENGINEERING CHANGE NOTICE

Date: 02.10.15		ECN #: 485			
Project No.: D350-600	Created By: <i>HA</i>	Checked By: <i>AP</i>			
Project Name: 350 SPACERODS	Approved By: <i>HA</i> (proj. manager)	Approved By: N/A (management if req'd)			
Description of Change: RELEASE DSI 9240 Rev. A					
Notification/Acceptance	Affected	Authorization			
QA	<input checked="" type="checkbox"/>	P302-501			
Production	<input checked="" type="checkbox"/>				
Planning	<input checked="" type="checkbox"/>				
Marketing	<input checked="" type="checkbox"/>				
Engineering Actions	Yes	No	Responsible	To happen by:	Complete
Update Blue File	<input checked="" type="checkbox"/>		KJ	02.10.15	02.10.15 <i>KJ</i>
Update Pink File	<input checked="" type="checkbox"/>		KJ	02.10.15	02.10.15 <i>KJ</i>
Update D-Part Master Binder		<input checked="" type="checkbox"/>			
Update Grey Project Binder	<input checked="" type="checkbox"/>		DS	02.10.15	02.10.15 <i>HA</i>
Update DEO Binder	<input checked="" type="checkbox"/>		DS	02.10.15	02.10.15 <i>HA</i>
Update Master Document List		<input checked="" type="checkbox"/>			
Update Drawing Approval Record	<input checked="" type="checkbox"/>		DS	02.11.15	03.04.25 <i>HA</i>
Update Change Record Form	<input checked="" type="checkbox"/>		DS	02.10.15	02.10.15 <i>HA</i>
Move Electronic File	<input checked="" type="checkbox"/>		DS	02.10.15	02.10.15 <i>HA</i>
Notify TCA of Change	<input checked="" type="checkbox"/>		DS	02.11.15	03.04.25 <i>HA</i>
Notify FAA of Change		<input checked="" type="checkbox"/>			
Update QSI 021		<input checked="" type="checkbox"/>			
Update QSI 036		<input checked="" type="checkbox"/>			
Scan Documents	<input checked="" type="checkbox"/>		KJ	02.10.15	02.10.15 <i>KJ</i>
Update MIS Database	<input checked="" type="checkbox"/>		KJ	02.10.15	02.10.15 <i>KJ</i>
Update Access Database	<input checked="" type="checkbox"/>		KJ	02.10.15	02.10.15 <i>KJ</i>
Verification ARC		<input checked="" type="checkbox"/>			
Notes:					
<p>- DSI 9240 Rev. A ADDED TO "600" BLUE/PINK FILES</p> <p>- DSI 9240-011 KIT CREATED IN MIS/ACCESS</p> <p>- MUEG TO SEND A DSI 9240-011 KIT TO GARY JONES @ AMERICAN BULDOZER ASAP.</p> <p>- UPDATE IPP & BOM FOR D350-600-041/-042 & D355-600-043 TO ADD 8 BOLTS & 8 INSERTS PER DSI 9240.</p> <p>- D350-600-041/-042 & D355-600-043 WILL BE AT <u>CHG 003</u> WITH 8 BOLTS & 8 INSERTS ADDED</p> <p>→ UPDATE PPP ACCORDINGLY.</p>					

U:\Admin\Forms\ECN-d1.xls

Rev.G

- CREATE IPP FOR DSI 9240-011

- A COPY OF DSI 9240 Rev. A MUST ACCOMPANY DSI 9240-011 KIT.